

FAÇADE WRAP FOR ALL WALL CONSTRUCTIONS

ONDUTISS® FACADE: this 3-layer high vapour permeable house wrap designed for all wall constructions, including timber, metal, and concrete, is a highly breathable housewrap, ideal for timber, concrete and steel framed constructions.

INSTALL STEPS

1. Fix the ridge batten support straps to each truss or rafter using clout head nails.



2. Lightly tense the wall membrane, and fix to the structure with staples or large head nails (roof nails).



3. Fix the next wall membrane strip, ensuring a minimum overlap of 30cm. Use the guidelines printed on the membrane to assist.



4. To eliminate air flow to the wall, it is best to seal the wall wrap overlaps with a double-sided tape. ONDUTISS FACADE is also available with integrated adhesive-strips.



5. A minimum of 2cm ventilation space should be kept between the wall wrap and the façade (cladding). for this purpose.)



onduline.com

Onduline
24, Quai Gallieni
92150 Suresnes, FRANCE

An Ondura Group Company

 **Ondura**
Protection above all